

AT31000 Assembly Instructions

4431000-200	1	Instruction manual
4531001	1	Fold-down splitting stand
4531002	1	Stationary stand
4531003	1	Balance stand assembly
4531004	1	Side mount plate (set of 2)
4531005	1	Single jack plate (set of 2)
4531006	1	Euro cradle attachment
4531008	6	Washer
4531009	4	Jack block
4531011	1	Wrench
4531007	2	6" extension jack block
4531016	2	3" extension jack block
4531017	2	9" extension jack block
4531013	6	Extension arm - Large Tractor Splitting System
4531015	1	Horizontal side mount plate (set of 2)
4531010	6	Pin
48590049	1	5/32 long arm hex key
43613-1	1	Bottom subassembly
43613-2	6	Post
43613-3	2	Front/Back sheet
43613-4	2	Side sheet
43613-5	1	Top sheet

STEP 1:



STEP 2:



STEP 3: Screw 2x post in place at back of crate (circled).



STEP 4:

Place in remaining part boxes (Place 4531008 & 48590049 in any other part box)

